
LD 20: Print Routine 1

Overlay program 20 allows data to be printed for the following blocks:

- all hunting
- group calls
- speed calls
- template data blocks
- terminal numbers
- pre-translation

Data Access Card (NT7D16)

By responding R232, R422, or DAC to the TYPE prompt in LD 20, you can print out the configured parameters for each port, or the entire DAC.

If a specific TN is entered, the current settings are uploaded from the unit and printed with the database settings. This is useful if parameters have been altered during keyboard or Hayes dialing modify procedures.

Templates

Templates store telephone information in system memory. Telephones with the same configuration of keys and Class of Service share the same template. This makes efficient use of Protected Data Store. Template Audit (LD 1) is used to remove unused templates.

Changes for Release 18

With Release 18 and later, when printing the TN block, “MARP” is output next to a DN appearance if it is the MARP TN for that DN. When printing the DN block, “MARP” is output prior to the DES if it is the MARP TN. Refer to X11 features and services for an explanation of the MARP feature.

With X11 Release 19 and later, the security password may be required to print telephone and TN information. The password (SPWD) is required if the Station Security Authcode package (229) is equipped and the password is defined.

Changes for Release 19

With Release 19 and later software, LDs 10, 11, 20 and 32 are linked thus eliminating the need to exit one Overlay and enter another. Once one of the above Overlays has been loaded it is possible to add, print and get the status of a set without having to exit one Overlay and load another. The input processing has also been enhanced. Prompts ending with a colon (:) allow the user to enter either:

- 1 a question mark (?) followed by a carriage return (<cr>) to get a list of valid responses to that prompt, or
 - 2 an abbreviated response, the system then responds with the nearest match. If there is more than one possible match the system responds with SCH0099 and the input followed by a question mark and a list of possible responses. The user can then enter the valid response.
-

Prompts and responses

Prompt	Response	Comment
REQ:	a...a	Request (REQ responses begin on page 533)
TYPE:	a...a	Type of data block (Type responses begin on page 536)
MODL	xxx	Option 11 Model number (1-3 digits)
TBNO	1-254	Table Number for 16-Button DTMF
TN	l s c u	Terminal Number (l s c u ranges are defined on page 535)
CDEN	aa	Card Density (aa = SD, DD, 4D, or 8D)
CUST	xx xx	Customer number
GRP	1-4095	Group number to be printed
MPHI	YES NO	Meridian Packet Handler Interface
SPWD	xxxx	Security Password
TEN	x...x	Tenant (0 or 1-511)
DN	x...x	Directory Number
DATE	dd mmm yyyy	Date
PAGE	(NO) YES	Data printed on a per-page basis
- ADJUST PAPER THEN <cr>		Adjust Paper so that printing starts at top of sheet
DES	d...d	Designator
NACT	(NO) YES	Next Activity
AACS	NO YES	Application acquired set
SCNO	0-8190	Speed Call list Number
LSNO	0-8190	Speed Call or System Speed Call List Number
RNGE	xxxx yyyy	Range of list entries to be printed, inclusive from first entry number to last entry number.
HTNO	xxxx	Hunt Number
DGRP	0-2045	Dial Intercom Group
DMEM	0-99	Dial Intercom Group (DIG) Member number
FOR	a...a	For telephone type (a...a = 500, 2xxx, or SL1)
KEY	(NO) YES	Print data for multi-line telephones
GRNO	0-63	Group Call Group Number
INFO	aaa	Information for templates (aaa = FRM, USE, USS, or DEF)
TEM	x...x	Template
EHNO	x...x	External Hunt DN

Alphabetical list of print reports

2.0 Mb/s Digital Trunk Interface (DT2) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	DT2	2.0 Mb/s DTI output
TN	l s c u	Terminal Number (loop, shelf, card, unit)
CUST	0-99	Customer number
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis

Analog set (500 & PBX) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	500	500/2500 type analog sets
	PBX	Private branch exchange sets
TN	l s c u	Terminal Number (loop, shelf, card, unit)
CDEN	SD, DD, 4D, 8D	Single, Double, Quad or Octal Density
CUST	0-99	Customer number
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis
DES	d...d	Print all units with DES "d...d"
	d+	Print all units starting with "d"
	<cr>	Disregard DES

Automatic Call Distribution Priority Agent (PRI2) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	PRI2	ACD Priority Agents
TN	l s c u	Terminal Number (loop, shelf, card, unit)
CUST	0-99	Customer number
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis

Attendant console (ATT, 1250, & 2250) data from LD 12

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	ATT	QCW3 or QCW4 Attendant Console
	1250	M1250 Console (Release 12 and later)
	2250	M2250 Console (Release 15 and later)
TN	l s c u	Terminal Number (loop, shelf, card, unit)
CDEN	SD, DD, 4D, 8D	Single, Double, Quad or Octal Density
CUST	0-99	Customer number
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis

Business Communicaton Set (BCS) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	BCS	Business Communication Sets
TN	l s c u	Terminal Number (loop, shelf, card, unit)
CDEN	SD, DD, 4D, 8D	Single, Double, Quad or Octal Density
CUST	0-99	Customer number
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis
DES	d...d	Print all units with DES "d...d"
	d+	Print all units starting with "d"
	<cr>	Disregard DES

Call Pickup Network Wide (CPNW) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	CPNW	Call Pickup Network Wide data
CUST	0-99	Customer number

Channel data: Real Analog, Virtual Analog and Virtual Digital

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	RAC	Real Analog Channels
	VAC	Virtual Analog Channels
	VDC	Virtual Digital Channels
TN	I s c u	Terminal Number (loop, shelf, card, unit)
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis

Class Modem unit data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	CMOD	CLASS modem unit
TN	I s c u	Terminal Number (loop, loop, shelf, card, unit)

Data access card (DAC) data

By responding R232, R422 or DAC to the type prompt in LD 20, the configured parameters for each port or the entire DAC may be printed.

If a specific TN is entered, the current settings are uploaded from the unit and printed with database settings. This is useful if parameters have been altered during keyboard or Hayes dialing modifying procedures.

Prompt	Response	Comment
REQ:	PRT, LTN, LUU	Print data, TN, or unit for the TN specified
TYPE:	DAC	Print data for whole DAC
	R232	Print data for the RS-232-C ports
	R422	Print data for the RS-422 ports
TN	l s c u	Terminal Number (loop, shelf, card, unit)
CUST	0-99	Customer number
DATE	dd mmm yyyy	Print data from the date specified
	ACT	Print data from the last Activity
PAGE	(NO) YES	Data printed on a per-page basis
DES	d...d	Print all units with DES "d...d"
	d+	Print all units starting with "d"
	<cr>	Disregard DES

Dial Intercom Group (DIG) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	DIG	Dial Intercom Group
CUST	0-99	Customer number
DGRP	0-2045	Dial Intercom Group
DMEM	0-99	Dial Intercom Group Member number

Dial Tone Detector (DTD & XTD) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	DTD	Dial Tone Detector data
	XTD	Extended Dial Tone Detector
TN	l s c u	Terminal Number (loop, shelf, card, unit)
CUST	0-99	Customer number
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis

Digital set (2000 series, 3000, & Aries) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	2xxx	Meridian 1 proprietary sets. You may enter: 2000, 2003, 2006, 2008, 2009, 2016, 2018, 2112, 2216, 2317, or 2616.
	ARIE	Aries (M2006, M2008, M2016S, M2216, or M2616) sets and Meridian Communications Unit (MCU) data blocks
	BCS	Business Communication Set
TN	l s c u	Terminal Number (loop, shelf, card, unit)
CDEN	SD, DD, 4D, 8D	Single, Double, Quad or Octal Density
CUST	0-99	Customer number
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis

Digitone Receiver (DTR) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	DTR	Digitone Receiver data
TN	l s c u	Terminal Number (loop, shelf, card, unit)
CDEN	SD, DD, 4D, 8D	Single, Double, Quad or Octal Density
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity

Directory number (DNB) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	DNB	Directory number data block
CUST	0-99	Customer number
DN	x...x	Print for Directory Number
DATE	dd mmm yyyy	Print data from the date specified
	ACT	Print data from the last Activity
PAGE	(NO) YES	Data printed on a per-page basis
DES	d...d	Print all units with DES "d...d"
	d+	Print all units starting with "d"
	+	Print units with no DES assignment
	<cr>	Disregard DES
ADJUST PAPER THEN <cr>		
	<cr>	Adjust paper so that printing starts at top of sheet

Directory number (DNB) range data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	DNB	Directory Number block
CUST	0-99	Customer number
DN	xxxx...xxxx	Up to 8 DNs can be entered
DATE	dd mmm yyyy	Print data from the date specified
	ACT	Print data from the last Activity
PAGE	(NO) YES	Data printed on a per-page basis
DES	d...d	Print all units with DES "d...d"
	d+	Print all units starting with "d"
	+	Print units with no DES assignment
	<cr>	Disregard DES
ADJUST PAPER THEN <cr>		
	<cr>	Adjust paper so that printing starts at top of sheet

Group Call (GRP) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	GRP	Group Call
GRNO	0-63	Group Call Group Number

Hot Line List (HTL) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	HTL	Hot Line List
CUST	0-99	Customer number
RNGE	xxxx...xxxx	Range of Hot Line list entries (0-1000) to be printed for this customer
	<cr>	Print all entries in the Hot Line list

Hunting (HNT, GHT, & EHT) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	HNT	Hunting
	EHT	External Hunting
	GHT	Group Hunting
CUST	0-99	Customer number
HTNO	x...x	Hunt Directory Number
EHNO	x...x	External Hunt Directory Number

Multifrequency (MFC, MFE, MFR, MFK5, MFK6 & MFVE) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	MFC	Multifrequency compelled sender/receiver
	MFE	Multifrequency signaling for Socotel sender/receiver
	MFR	Multifrequency receiver (for Feature group D)
	MFVE	Multifrequency versatile units
	MFK5	2/5 Spanish KD3 MF signaling
	MFK6	2/6 Spanish KD3 MF signaling
TN	I s c u	Terminal Number (loop, shelf, card, unit)
	I ch	DTI/PRI loop and channel
CDEN	SD, DD, 4D, 8D	Single, Double, Quad or Octal Density
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis

Out of Service unit (OOSLT & OOSMLT) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	OOSLT	Single line TNs that are Out-of-Service
	OOSMLT	Multi-line TNs that are Out-of-Service
TN	I s c u	Terminal Number associated with the unit

Power (PWR) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	PWR	Power data block
TN	I s c u	Terminal Number (loop, shelf, card, unit)
CDEN	SD, DD, 4D, 8D	Single, Double, Quad or Octal Density
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis

Pretranslation (PRE) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	PRE	Pretranslation
CUST	0-99	Customer number

SL1 set data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	SL1	SL1 and M1109 sets, QCW and M1250 console
TN	I s c u	Terminal Number (loop, shelf, card, unit)
CDEN	SD, DD, 4D, 8D	Single, Double, Quad or Octal Density
CUST	0-99	Customer number
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis

Special Service List (SSL) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	SSL	Special Service List
SSL	1-15	Special Service List number

Speed call lists (SCL) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	SCL	Regular and System Speed Call Lists
LSNO	0-8190	List Number for Speed Call or System Speed Call
	<cr>	Print for all lists
RNGE	xxxx xxxx	Range of Speed Call entries (0-1000) to be printed
	<cr>	Print all entries

Tandem Connection (TCON) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	TCON	Tandem Connection for Meridian Packet Handler and PRI connections

Template (TEM) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	TEM	Templates
FOR	aaa	Print template information for telephone type
INFO	FRM	Print key/feature assignment template
	USE	Print number of users of the template
	USS	Print TN using the template
	DEF	Print number of templates defined and the number of templates allowed
TEMP	xxxx	Telephone template number
	<cr>	Print all templates

Terminal Number Block (TNB) data for telephones and trunks

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	TNB	Terminal Number Block
TN	l s c u,...	Terminal Number (Up to 6 TNs can be entered)
CDEN	SD, DD, 4D, 8D	Card Density
CUST	xx xx	Customer number
MPHI	YES, NO	Meridian Packet Handler Interface
SPWD	xxxx	Security Password
TEN	0, 1-511	Tenant
DATE	dd mmm yyyy	Print data from date specified
PAGE	(NO) YES	Date printed on a per page basis
DES	d...d, d+, +	Designator
NACT	(NO) YES, END	Next Activity
AACS	a...a	Application acquired set (a...a = (NO), AGTH, or AGT)
ASID	x...x	Application Service ID
SMCB	1-17	Print set message control bitmap
SMOO	(NO) YES	(Do not set) Set message optimize option

Terminal Number Block (TNB) range data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	TNB	Terminal Number Block
TN	l s c u-l s c u	Terminal Number Range

Tone Detector (TDET) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	TDET	Tone Detector data
TN	l s c u	Terminal Number (loop, shelf, card, unit)
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis

Trunk data: All Trunks

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	TRK	Trunk data block
TN	l s c u	Terminal Number (loop, shelf, card, unit)
CDEN	SD, DD, 4D, 8D	Single, Double, Quad or Octal Density
CUST	0-99	Customer number
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis

Trunk data: Specific Trunk types

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	ADM	Add-on Data Module (Release 5 & later)
	AWR	Automatic Wake-Up RAN/Music trunks (Release 10 & later)
	CAA	Common Control Switching Arrangement
	CAM	CAMA trunks
	COT	Central Office trunks
	CSA	Common control switching arrangement access line
	DIC	Dictation trunks
	DID	Direct inward dial trunks
	FEX	Foreign Exchange trunks
	FGDT	Feature Group D trunks
	IDA	Integrated digital access trunks
	ISA	Integrated services access trunks (ISDN)
	MCU	Meridian Communications Unit (Release 19 & later)
	MDM	Modem/Data Module
	MUS	Music trunks
	PAG	Paging trunks
	R232	RS-232 mode data
	R422	RS-422 mode data
	RAN	Recorded announcement trunks
	RCD	Recorder trunks
	RDC	Real digital channel
	RLM	Release Link Main trunks
	RLR	Release Link Remote trunks
	TIE	TIE trunks
	WAT	Wide Area Telephone service trunks
TN	I s c u	Terminal Number (loop, shelf, card, unit)
CDEN	SD, DD, 4D, 8D	Single, Double, Quad or Octal Density
...		

LD 20

Prompt	Response	Comment
CUST	0-99	Customer number
DATE	dd mmm yyyy	Print data from date specified
	ACT	Print data from last activity
PAGE	(NO) YES	Data printed on a per page basis

Unused Card (LUC) data

Prompt	Response	Comment
REQ:	LUC	List Unused Card slots
TN	l s c	Terminal Number (loop, shelf, card)
	l ch	DTI/PRI loop and channel

Unused Directory Number (LUDN) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	LUDN	List Unused Directory Numbers
CUST	0-99	Customer number
DN	xxxx-xxxx	DN range

Unused Units (LUU) data

Prompt	Response	Comment
REQ:	LUU	List Unused Units
TYPE:		Peripheral equipment requiring TNs:
	500	Single line or analog sets
	SL1	SL-1 sets, QCW and M1250 consoles
	2000	Digital sets and M2250 consoles
	DTR	Digitone Receiver
	DSL	Digital Subscriber Loop
	MCU	Meridian Communications Unit
	TRK	All trunks
	a...a	Any specific trunk type (e.g., COT, DID, FEX, WAT, etc.)
TN	I s c u	Terminal Number

Unused Voice or Data unit (LUVU or LUDU) data

Prompt	Response	Comment
REQ:	LUVU	List Unused Voice Units
	LUDU	List Unused Data Units
TYPE:		Peripheral equipment requiring TNs:
	500	Single line or analog sets
	SL1	SL-1 sets, QCW and M1250 consoles
	2000	Digital sets and M2250 consoles
	DTR	Digitone Receiver
	DSL	Digital Subscriber Loop
	MCU	Meridian Communications Unit
	TRK	All trunks
	a...a	Any specific trunk type (e.g., COT, DID, FEX, WAT, etc.)
TN	xx...xxxx	Terminal Number

Voice Mailbox (VMB) data

Prompt	Response	Comment
REQ:	PRT	Print
TYPE:	VMB	Voice Mailbox information
CUST	<cr>	Customer number automatically appears. No entry is needed.
DN	xxxx	Print for Directory Number
VMB_STATE	nnnn	Print based on Voice Mailbox State

Alphabetical list of prompts

Prompt	Response	Comment	Pack/Rel
AACS	NO YES	Application acquired set The TN is not acquired by an application The TN is acquired by an application	nxcc-22
ADJUST PAPER THEN <cr>	<cr>	Adjust paper then <cr> to start printing Start printing	basic-1
ASID	x...x	Application Service ID from which the acquired request originated The ASID is used for sending the monitor/control messages to the application. The ASID value is updated based on the applications's Acquire message for the TN. Since the AML over Ethernet (ELAN) is used to communicate between the Meridian 1 and the application(s), the value of the existing VSID might be used to uniquely identify the application that has acquired this device. ASID is printed if AACS = YES.	nxcc-22
CALB	1 2 ...	Call Filter Bitmap CALB applies to messages such as PCI, DN update, etc. This bitmap is downloaded by the application which is used to control the sending of messages on behalf of the acquired TN. A numeric value would only be printed if the corresponding set message is enabled. CALB is printed if AACS = YES.	nxcc-22
CDEN	SD DD 4D 8D <cr>	Single Card Density Double Card Density Quadruple Card Density Octal Card Density For all card densities	basic-7

LD 20

Prompt	Response	Comment	Pack/Rel
CUST	xx xx	Customer number Print data range from first to last customer. Not prompted when: 1. REQ = LUU or LUC 2. TYPE = SCL, DIG or TEM 3. a complete TN is entered	basic-1
	<cr>	Print data blocks for all customers	
DATE	dd mmm yyyy	Print data from date specified. Where: • dd = 1-31 • mmm = JAN-DEC • yyyy = year (e.g. 1993)	basic-1
	<cr> ACT	DATE is prompted for TN related data. Print data and show last activity date. Print data from last activity date.	
DES		Designator	odas-1
	d...d d+ + <cr>	Print all units with ODAS designator d...d Print units starting with ODAS designator d Print units with no ODAS designator assigned Disregard ODAS designator DES is prompted on TN related data The printing of data is subject to restrictions imposed by responses to TN and DATE.	
DGRP		Dial Intercom Group	basic-1
	0-254 0-2045 <cr>	DIG numbers per customer (Release 13 and earlier) Release 14 and later Print all Dial Intercom Groups for customer DGRP is prompted when TYPE = DIG	
DMEM		Dial Intercom Group (DIG) Member number	basic-1
	0-99 <cr>	Print all DIG member numbers	

Prompt	Response	Comment	Pack/Rel
DN		Directory Number	basic-19
	xxxx	Print data block for DN	
	<cr>	Print data blocks for all DN	
	xxxx <space>	If a space is entered after the Directory Number the system will reprompt for DN. A maximum of six DNs can be stacked and printed at one time.	
		With Release 19 and later the following responses are valid for DN:	
	x<cr>	All DNs starting with first digit x (X000-X999)	
	xx<cr>	All DNs starting with first two digits xx (XX00-XX99)	
	xxx<cr>	All DNs starting with first three digits xxx (XXX0-XXX9)	
	x-<cr>	All DNs between X000-9999	
	x-y<cr>	All DNs between DN X000 through Y999	
	xx-yyy<cr>	All DNs between DN XX00 through YYY9	
	xxxx xxxx	Two specific DNs. Up to a maximum of 8 DNs.	
	xxxx-yyy	All DNs between XXXX and YYYY	
EHNO	xxxx	External HUNT DN Up to 4 digits, up to 7 digits with Directory Number Expansion (DNXP) package 150. EHNO is prompted when TYPE = EHT	eht-10
FOR		Print template information for telephone type	basic-1
	500	Print data for 500/2500 telephones.	
	2xxx	Print data for 2000 type telephones (specify type).	
	SL1	Print data for SL-1 telephones.	
GRNO	0-63	Group Call Group Number. Prompted when TYPE = GRP.	grp-1
	<cr>	Print all group call groups.	
GRP	1 - 4095	Group number to be printed	grp-21
	<CR>	All groups assigned to a speed call list are printed.	

LD 20

Prompt	Response	Comment	Pack/Rel
HTNO	x...x	Hunt Directory Number Up to 4 digits, up to 7 digits with Directory Number Expansion (DNXP) package 150. Prompted when TYPE = HNT.	basic-1
INFO	FRM USE USS DEF	Information for Templates Print key/feature assignment template Print number of users of template Print TN using the template Print number of templates defined and number allowed Prompted when TYPE = TEM	basic-1
KEY	(NO) YES	Print data for multi-line telephones Print data for 500/2500 telephones Print data for SL-1, digital and touch telephones Prompted when TYPE = TEM (Release 5 or earlier).	basic-1
LSNO	0-253 0-4095 0-8190	Speed Call or System Speed Call List Number prior to Release 14 System Speed Call Lists Release 14 and later Speed Call Lists Release 14 and later When inputting list number for printout, non-DN input exceeding 4 digits may be truncated. Only the 4 right-most digits will be accepted, and printed for Release 14 and later.	basic-1
MODL	xxx	Option 11 Model number (1-3 digits)	basic-15
MPHI	YES NO	Meridian Packet Handler Interface. Prompted when TYPE = MCU. Respond Yes if using the MCU for MPH interfaces.	mph-19
NACT	(NO) YES END	Next Activity Return to REQ prompt Print current system data and end overlay End overlay activity	odas-1
PAGE	(NO) YES	Data printed on a per-page basis Prompted only on TN related data	basic-1

Prompt	Response	Comment	Pack/Rel
REQ:		Request	basic-1
	END	Exit overlay program	
	LTN	List TN of TYPE specified	
	LUC	Print Unused Card data blocks of TYPE specified	
	LUDU	List Unused Data Units	
	LUU	Print Unused Unit data blocks of TYPE specified	
	LUVU	List Unused Voice Units	
	PRT	Print data block for the TYPE specified.	

Note: As of Release 19, this load is linked with LDs 10, 11 and 32. You may enter one of the responses listed below to the REQ: prompt. Then go to that Load and follow its Prompt and Response sequence. See "Changes for Release 19" on page 508 for further information.

LD 32: CDSP CMIN CONV CPWD DISC DISI
DISL DISN DISS DISU DSCT DSPS
DSXP ENCT ENLC ENLG ENLL ENLN
ENLS ENLU ENPS ENXP IDC IDCS
IDU LBSY LDIS LIDL LMNT PBXT
SDLC STAT SUPL TRK XNTT XPCT
XPEC

LD 10 or 11: CHG CPY MOV NEW OUT

RNGE	xxxx yyyy <cr>	Range of list entries to be printed, inclusive from first entry number to last entry number. Print All members of a specified SCL or SSC list.	optf-1
SCNO	0-253 0-8190 <cr>	Speed Call list Number Speed Call list Number - Release 13 and later Print all lists. Prompted when TYPE = SCL	optf-1
SFNB	1 2 ...	Set Feature Notification Bitmap SFNB is used for messages such as: SFN (login), SFN (logout), ... This bitmap is downloaded by the application which is used to control the sending of SFN messages on behalf of the acquired TN. A numeric value is printed only if the corresponding message is enabled. SFNB is printed if AACS = YES.	nxcc-22

LD 20

Prompt	Response	Comment	Pack/Rel
SFRB	1 2 ...	Set Feature Route Bitmap SFRB is used for messages such as: SFR (login), SFR (logout), ... This bitmap is downloaded by the application which is used to control the sending of SFR messages on behalf of the acquired TN. A numeric value is printed only if the corresponding message is enabled. SFRB is printed if AACS = YES.	nxcc-22
SPWD	xxxx	Security Password. This prompt appears when: 1. the Station Specific Authcode package (229) is equipped 2. the security password is defined in LDs 10 and 11.	ssau-19
TBNO	1-254	Table Number for 16-Button DTMF Prompted when TYPE = ABCD	supp-10
TEM	xxxx xxxxxxx <cr>	Template number Template number - Release 13 and later Print data for all templates. Prompted when TYPE = TEM	basic-1
TEMP	xxxx	Telephone template number. Enter <cr> to print all templates.	basic-1
TEN	0 1-511 <cr>	Tenant Shared customer resource stations Tenant Service stations Print data blocks for all tenants.	tens-7

Prompt	Response	Comment	Pack/Rel
TN		Terminal Number	basic-1
	loop	Print data of the specified TYPE for this loop.	
	l s	Print data of the specified TYPE for this loop and shelf	
	l s c	Print data of the specified TYPE for this loop, shelf and card	
	l s c u	Print data of the specified TYPE for this loop, shelf, card and unit.	
	l ch	Print data of the specified TYPE for this loop and channel (format for Digital Trunk and Primary Rate Interfaces).	
	card	Print data of the specified TYPE for this card (Option 11).	
	c 0 0 u	For Option 11	
	c u	Print data of the specified TYPE for this card and unit (Option 11).	
	c ch	Print data of the specified TYPE for this card and channel (digital trunks only) (Option 11).	
	n. . . n<space>	System will prompt for TN. A maximum of six TNs can be stacked and printed at one time.	
	<cr>	Print data for all TNs of the specified TYPE. With Release 19 and later the following responses are valid for TN.	
	l s c u, l s c u	List of TNs (up to 6)	
	l s c u, l ch	A TN and a trunk loop/channel can be entered on the same line	
	l s c, l s c	All units within the specified starting and ending cards	

LD 20

Page 536 of 1004 Alphabetical list of prompts

Prompt	Response	Comment	Pack/Rel
	I s, I s c u	All units, including the specified starting shelf and ending TN	
	I s c u	All TNs starting with the specified TN and ending with the last TN	
		Not prompted when TYPE = SCL, HNT, DIG, TEM, or GRP	
TYPE:		Type of data block	basic-1
Note: For Release 19, this load is linked with LDs 10, 11 and 32. LD 20 permits you to enter LD 10 or 11 responses to the TYPE prompt or a command listed in LD 32. See “Changes for Release 19” on page 508 for further information.			
500		500/2500 telephone	
500 M		Option 11 Model	
1250		M1250 Console (Release 12 and later)	
2000		M2000 type digital telephones	
2003		2003 Digital telephone	
2006		M2006 Digital telephone (Release 15 and later)	
2006 M		Option 11 Model	
2008		M2008 Digital telephone (Release 14 and later)	
2008 M		Option 11 Model	
2009		M2009 Digital telephone (Release 7 and later)	
2009 M		Option 11 Model	
2016		M2016 Digital telephone	
2018		M2018 Digital telephone (Release 7 and later)	
2018 M		Option 11 Model	
2112		M2112 Digital telephone (Release 7 and later)	
2112 M		Option 11 Model	
2216		M2216 Digital telephone (Release 14 and later) (ACD terminal)	

Prompt	Response	Comment	Pack/Rel
	2216 M	Option 11 Model	
	2250	M2250 Console (Release 15 and later)	
	2317 2317 M	M2317 Digital telephone (Release 9 and later) Option 11 Model	
	2616 2616 M	M2616 Digital telephone (Release 14 and later) Option 11 Model	
	3000 3000 M	M3000 Digital Touchphone (Release 7 and later) Option 11 Model	
	4020	M4020 Model	
	ABCD	16-Button DTMF	
	ADM	Add-on Data Module (Release 5 and later)	
	ADM M	Data port interfacing with a data line card Option 11 Model	
	ARIE	Aries (M2006, M2008, M2016S, M2216 and M2616) sets and Meridian Communications Unit (MCU) data blocks	
	ATT	QCW3 or QCW4 Attendant Console	
	AWR	Automatic Wake Up RAN/Music trunk (Release 10 and later)	
	AWR M	Option 11 Model	
	BCS	Business Communication Set	
	CAA	Common Control Switching Arrangement (CCSA) Automatic Number Identification (ANI) trunk data block	
	CAA M	Option 11 Model	
	CAM CAM M	CAMA trunk data block Option 11 Model	
	COT COT M	Central Office Trunk (PSTN) data block Option 11 Model	
	CPNW	Call Pickup Network Wide data	

LD 20

Page 538 of 1004 Alphabetical list of prompts

Prompt	Response	Comment	Pack/Rel
	CSA	Common Control Switching Arrangement access line	
	CSA M	Option 11 Model	
	DAC	Data Access Card	
	DIC	Dictation trunk data block	
	DIC M	Option 11 Model	
	DID	Direct Inward Dialing trunk data block	
	DID M	Option 11 Model	
	DIG	Dial Intercom Group	
	DNB	Directory Number Block	
	DSL	Digital Subscriber Loop (S/T or U I/F for ISDN BRI)	
	DT2	2.0 Mb/s DTI output only	
	DTD	Dial Tone Detector	
	DTR	Digitone Receiver	
	EHT	External Hunting	
	FEX	Foreign Exchange trunk	
	FEX M	Option 11 Model	
	FGDT	Feature Group D Trunk	
	GHT	Group Hunt	
	GRP	Group call	
	HNT	Hunting	
	HTL	Hot Line	
	IDA	Integrated Digital Access	
	ISA	Integrated Services Access trunk (ISDN)	

Prompt	Response	Comment	Pack/Rel
	LUDN	List Unused Directory Numbers.	
	MCA MCA M	Meridian Communications Adapter Release 18 Option 11 Model	
	MCU	Meridian Communications Unit Release 19 and later	
	MDM MDM M	Modem/Data Module. Data port interfacing with QPC60 500/2500 type card Option 11 Model	
	MFC	Multifrequency Compelled sender/receiver data block	
	MFE	Multifrequency Signaling for Socotel sender/receiver	
	MFK5	2/5 Spanish KD3 MF Signaling	kd3-20
	MFK6	2/6 Spanish KD3 MF Signaling	kd3-20
	MFR	Multifrequency Receiver (for Feature Group D)	
	MFVE	Print Multifrequency Versatile units	
	MUS MUS M	Music trunk Option 11 Model	
	OOSMLT	Out-of-Service Multi-Line Terminal	xpe-20
	OOSSLT	Out-of-Service Single Line Terminal	xpe-20
	PAG PAG M	Paging trunk Option 11 Model	
	PBX	PBX sets	
	PRE	Pretranslation	
	PRI2	ACD Priority Agents	
	PWR	Power data block	
	R232 R232 M	NT7D16 Data Access Card (Release 16 and later) (DAC) port in RS-232 Data mode data block Option 11 Model	

LD 20

Prompt	Response	Comment	Pack/Rel
	R422	NT7D16 Data Access Card (Release 16 and later) (DAC) port in RS-422 mode data block	
	R422 M	Option 11 Model	
	RAC	Real Analog Channel	
	RAN	Recorded Announcement trunk	
	RAN M	Option 11 Model	
	RCD	Recorder trunk	
	RDC	Real Digital Channel	
	RLM	Release Link Main trunk	
	RLM M	Option 11 Model	
	RLR	Release Link Remote trunk	
	RLR M	Option 11 Model	
	SCL	Regular and System Speed Call Lists	
	SL1	SL-1 and M1109 sets, QCW and M1250 console (Not supported on Option 11)	
	SSL	Special Service List	
	TCON	Tandem Connection for MPH and PRI connections	
	TDET	Tone Detector	
	TEM	Template	
	TIE	TIE trunk	
	TIE M	Option 11 Model	
	TNB	Terminal Number	
	TRK	Trunk data block	
	VAC	Virtual Analog Channel	
	VDC	Virtual Digital Channel	

Prompt	Response	Comment	Pack/Rel
	VMB	Voice Mailbox information	
	WAT WAT M	Wide Area Telephone Service trunk Option 11 Model	
	XTD	Extended Dial Tone Detector and Digitone Receiver	
	<cr>	Print all	
USFB	1 2 ...	Unsolicited Status Message (USM) Filter Bitmap USFB applies to messages such as: Onhook, Offhook, Ringing, Active, Disconnect, Unringing, Hold, Restore, Ready, Not Ready, Walkaway, Walkaway Return, Reserved, Unreserved, ... This bitmap is downloaded by the application which is used to control the sending of USM messages on behalf of the acquired TN. A numeric value would only be printed if the corresponding message set is enabled. USFB is printed if AACS = YES.	nxcc-22
VMB_STATE	nnnn	Print based on Voice Mailbox State	vmba-19

